

Storage Recommendations for Atlas ACFoam[®] Products

| ISSUED: | 10/26/2017 |
|-----------|------------|
| *UPDATED: | 08/19/2024 |
| PAGES: | 01 |

'SUPERSEDES EXISTING DOCUMENTS

Factory applied packaging is intended only for protection during transit. When stored outdoors or on the job site, the insulation should be stacked on pallets at least three inches above ground level and completely covered with a weatherproof covering such as a tarpaulin. The temporary factory-applied packaging should be slit or removed to prevent accumulation of condensation. Roof insulation which has become wet or damaged should be removed and replaced with solid, dry insulation, of the same type.

For additional storage and handling recommendations, see PIMA Technical Bulletin #109.



Atlas Roofing Corporation 2000 Riveredge Parkway, Suite 800 • Atlanta, GA • 30328 770-952-1442 • atlasrwi.com